


V8-S FLASHLIGHT INSTRUCTION MANUAL



WARNING:

- Do not shine directly in the eyes, the powerful LED light will damage the eyes immediately.
- If the battery is not used for a long time, please charge and discharge it every 3 months to keep the battery in good condition.
- 3. It is normal to use the lights for a long time to heat up.
- When the indicator light shows low power, please charge the battery as soon as possible.
- 5. Please keep the battery away from water, moisture and drop etc.
- To avoid damage to the surface of the flashlight, please do not expose the flashlight to sunlight, water, chemicals, corrosive gases or any other oxidizing environment frequently.
- 7.Before use, please tear off the transparent film on the battery surface before use.

INSTRUCTIONS FOR USE



USB Charging treasure function

- 1.Normal Modes: Press the switch button to turn on the light source, and continue to press the mode (low light-medium light-strong light-strobe-SOS-off) to cycle in sequence. Press and hold any mode for 2s to close;
- 2.Zoom Modes:Focusing and floodlight functions of the flashlight can be performed by adjusting the focus by extending the head.
- When charging, the red indicator light flashes; when fully charged, the blue indicator light is always on.

PRODUCT PARAMATERS

Model	V8-S	Power	36w
Charging ways	Type-C	Weight	205G
Battery	26650	Size	159*40*35mm
Mode	Low Light-Medium Light-Strong Light-Strobe-SOS-Off		

APPLICATION SCENARIO











Camping

Mountaineering

Capture

GO fishing

Rock climbing



Cycling



Motion



Construction



Explore



Repair

Warranty card

User name:
Phone number:
Thorie number.
E mail:
E-mail:
A diducino.
Address:
Other Contacts:
Release Date: